



CABLE COLOUR CODE

B - BLACK
 G - GREEN
 R - PINK
 LG - LIGHT GREEN
 N - BROWN
 O - ORANGE
 P - PURPLE
 R - RED
 U - BLUE
 W - WHITE
 Y - YELLOW

MOKE - KEY TO WIRING DIAGRAM

- | | | | | |
|--|--|---|---------------------------------------|---------------------------------------|
| 1 - ALTERNATOR | 11 - WINDSCREEN WASHER MOTOR | 21 - REAR DIRECTION INDICATOR LAMP LH | 31 - HORN | 41 - FUEL LEVEL INDICATOR |
| 2 - BATTERY | 12 - HEADLAMP DIP BEAM | 22 - REAR FOG-GUARD LAMP SWITCH | 32 - REVERSE LAMP SWITCH | 42 - FUEL LEVEL INDICATOR-TANK UNIT |
| 3 - STARTER MOTOR SOLENOID | 13 - HEADLAMP MAIN BEAM | 23 - REAR FOG-GUARD LAMP | 33 - REVERSE LAMP | 43 - OIL PRESSURE WARNING LAMP |
| 4 - STARTER MOTOR | 14 - SIDE LAMPS | 24 - REAR FOG-GUARD WARNING LAMP | 34 - STOP LAMP SWITCH | 44 - OIL PRESSURE SWITCH |
| 5 - IGNITION/STARTER SWITCH | 15 - FRONT DIRECTION INDICATOR LAMP LH | 25 - LINK FUSE | 35 - STOP LAMP | 45 - NO CHARGE WARNING LAMP |
| 6 - HEATER MOTOR | 16 - FRONT DIRECTION INDICATOR LAMP RH | 26 - BRAKE PRESSURE DIFFERENTIAL SWITCH | 36 - HAZARD WARNING FLASHER UNIT | 46 - MAIN BEAM WARNING LAMP |
| 7 - HEATER SWITCH (WHEN FITTED) | 17 - HEAD LAMP FLASH SWITCH | 27 - BRAKE FAILURE TEST SWITCH WARNING LAMP | 37 - DIRECTION INDICATOR FLASHER UNIT | 47 - TAIL LAMP RH |
| 8 - FUSE BOX | 18 - HORN PUSH | 28 - IGNITION COIL | 38 - HAZARD WARNING SWITCH | 48 - TAIL LAMP LH |
| 9 - WINDSCREEN WIPER MOTOR | 19 - HEADLAMP DIP SWITCH | 29 - DISTRIBUTOR | 39 - PANEL ILLUMINATION LAMPS | 49 - DIRECTION INDICATOR-WARNING LAMP |
| 10 - CONTINUED WINDSCREEN WIPER AND WIPER SWITCH | 20 - REAR DIRECTION INDICATOR LAMP RH | 30 - LIGHTING SWITCH | 40 - VOLTAGE REGULATOR | 50 - DIODES |

51 - BALLAST RESISTOR (CIRCUIT)

15A. FRONT SIDE LAMP BEAM (SEE DRAWING)

15B. FRONT SIDE LAMP BEAM (SEE DRAWING)

① - Time of flame - 1/1000 sec. or less (1/1000 sec.)
 ② - diameter - 0.015 in.

MOKE

WIRING DIAGRAM