





Centrale clignotante
d'indicateur de
direction/signal de détresse
Femelle
NOIR
Derrière le centre du tableau



Blink-/Warnblinkgerät
Buchse
SCHWARZ
Hinter der Mitte des
Armaturenbretts



Unità avvisatori di
pericolo/indicatori di direzione
Femmina
NERO
dietro il centro della plancia

Ca v	Col	Cct
85	PO	ALL
86	B	ALL
87	LGK	ALL